

# Opel Vivaro-e

## Kuinka latauskaapeli irrotetaan

1. Avaa auton lukitus sovelluksesta.
2. Irroita latauskaapeli autosta ja latausasemasta, sulje latausluukku.
3. Sijoita auton mukana kulkeva latauskaapeli auton takatavaratilaan.

## Kuinka autolla lähdetään liikkeelle

1. Istu autoon ja paina jarrupoljin pohjaan.
2. Ota auton avain hanskalokerosta ja laita se virtalukkoon.
3. Kytke turvavyö.
4. Käynnistä auto kääntämällä avainta.
5. Vedä vaihteenvälitsin **Drive (D)** – asentoon (ajovaihde) tai työnnä vaihteenvälitsin **Reverse (R)** – asentoon (peruutusvaihde).
6. Nosta jalka jarrupolkimelta ja paina kaasupoljinta vähän kerrallaan. Käsijarru vapautuu automaattisesti liikkeelle lähdettäessä. Mikäli käsijarru ei vapaudu automaattisesti, paina jarrupoljin pohjaan ja paina käsijarrukytkintä alaspäin jotta käsijarru vapautuu.

## Kuinka ajo lopetetaan

1. Pidä jarrupoljinta pohjassa.
2. Paina vaihteenvälitsimen vieressä olevaa **P** painiketta, jolloin pysäköintivaihde **Park (P)** kytkeytyy. Käsijarru kytkeytyy automaattisesti.
3. Sammuta auto kääntämällä avainta ja palauta avain hanskalokeroon.
4. Poistu autosta ja kytke latauskaapeli.
5. Lukitse auto sovelluksesta.

### Ongelmatilanteissa:

sharing@aimopark.fi | 020 7812 490

## Kuinka auton vaihteita käytetään

Auton vaihdevalitsin sijaitsee auton keskikonsolissa ja toimii vetämällä ja työntämällä.

### **Drive (D)** - ajovaihde

Vedä vaihteenvälitsinta itseäsi kohti kunnes vaihde kytkeytyy. Voit valita ajovaihteen kun auto on paikallaan.

### **Park (P)** - pysäköintivaihde

Kun auto on paikallaan, paina vaihdevalitsimen päässä olevaa **P-painiketta**, jolloin pysäköintivaihde **Park (P)** kytkeytyy. Pysäköintijarru kytkeytyy automaattisesti.

### **Reverse (R)** - peruutusvaihde

Työnnä vaihteenvälitsinta eteenpäin kunnes vaihde kytkeytyy. Voit valita peruutusvaihteen, kun auto on pysäytetty.

### **Neutral (N)** - vapaa

Työnnä vaihteenvälitsinta hieman eteen tai vedä hieman taakse, riippuen siitä onko kytkettynä **P**, **R** tai **D**. Vapaan ollessa kytkettynä, auto kulkee vapaasti mikäli et paina jarrupoljinta.

### **Huom!**

Auton vaihdevalitsin ei jää fyysisesti valinnan mukaiseen kohtaan, vaan palautuu aina keskelle. Tämä kuuluu asiaan.

# Opel Vivaro-e

## How to disconnect the charging cable

1. Unlock the car using the app.
2. Disconnect the charging cable from the car and the charging station, then close the charging port.
3. Place the charging cable provided with the car into the car.

## How to start driving the car

1. Sit in the car and press the brake pedal firmly.
2. Take the car key from the glove compartment and insert it into the ignition.
3. Fasten your seatbelt.
4. Start the car by turning the key.
5. Move the gear selector to the **Drive (D)** position for forward driving or to the **Reverse (R)** position for reversing.
6. Lift your foot off the brake pedal and gently press the accelerator pedal. The parking brake will release automatically as the car starts moving. If the parking brake does not release automatically, press the brake pedal fully and push the parking brake switch down to release the parking brake.

## How to stop driving

1. Keep the brake pedal pressed.
2. Press the P button located next to the gear selector to engage the parking gear **Park (P)**. The parking brake will engage automatically.
3. Turn off the car by turning the key and return the key to the glove compartment.
4. Exit the car and connect the charging cable.
5. Lock the car using the app.

### Problem situations:

sharing@aimopark.fi | +358 (0)20 7812 490

## How to use the car's gear selector

The gear selector is located on the car's center console and operates by pulling and pushing.

### Drive (D) - driving gear

Pull the gear selector towards yourself until the gear engages. You can select the driving gear while the car is stationary.

### Park (P) - parking gear

When the car is stationary, press the P button next to the gear selector to engage the parking gear **Park (P)**. The parking brake will engage automatically.

### Reverse (R) - reverse gear

Push the gear selector forward until the gear engages. You can select reverse gear when the car is stopped.

### Neutral (N) - neutral gear

Push the gear selector slightly forward or pull it slightly backward, depending on whether P, R, or D is engaged. In Neutral, the car will roll freely unless the brake pedal is pressed.

### Please note!

The gear selector does not stay in the physical position corresponding to the gear selection but always returns to the center position. This is intentional.